

Connecting Rod replacement.

Either remove foot tray or work with it in position. Example is with foot tray removed. This is done by removing retaining screws on top of foot tray using an Alan key .

1. Set front of buggy out as pic 1
2. Cut Old connecting rod off, just in front of collar using a hack saw. Pic 2
3. You will see tube is visible when bar is removed . Pic 3
4. Clean up inside of tube removing burs etc with file Pic 4
5. Place new connecting rod inside of tube Pic 5
6. Lower frame and rod to floor Pic 6
7. Using a 6mm drill tip. Mark and drill a vertical hole approx 30mm from end of rod (nearest the front), through tube and new rod. Pic 7
8. Insert 6mm fixing bolt (with washer at the top) in to hole and tighten nut Pic 8
9. Refit foot trat if removed, finished



Pic 1



Pic 4



Pic 7



Pic 2



Pic 5



Pic 8



Pic 3



Pic 6



Pic 9